



# PARTS BREAKDOWN

## AIR COMPRESSOR

MODEL:AC104



**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN AIR COMPRESSOR

MODEL:AC104

## PUMP AND MOTOR ASSEMBLY




REF #	DESCRIPTION	QTY	BE PART #
7	Piston Ring	2	42.011.027
8	Piston	2	
9	Inner Hexagon Screws	2	
10	Cylinder	2	
13	Air Filter Assembly	1	42.011.001
18	Discharge Elbow	3	42.011.028
27	Shock Pad (Set of 4)	4	42.011.029
28	Cable Retaining Clip	2	42.011.030
46	Waterproof Nut	1	42.011.032
47	Cross Joing Screw M5*14	2	
48	Connecting Box	1	
49	Capacitor	1	42.011.034
50	Wiring Cap	2	85.506.031
Not Shown	Black Plastic Pump Cover	2	42.011.033
1-36	Motor Pump Assembly Kit	1	42.011.036



# PARTS BREAKDOWN AIR COMPRESSOR


MODEL:AC104

## PRESSURE SWITCH ASSEMBLY



REF NO.	DESCRIPTION	QTY	PART NO.
56	Safety Relief Valve	1	42.010.150
58	Pressure Switch	1	42.011.009

## TANK ASSEMBLY



REF NO.	DESCRIPTION	QTY	PART NO.
47	Discharge Pipe M14	2	42.011.024
53	Check Valve	1	
54	Release Pipe	1	
45	Quick Coupler	2	42.011.012
46	Pressure Gauge	2	42.011.013
49	Foot (Set of 4)	4	42.011.014
44	Regulator with Manifold	1	42.011.026
51	Tank Drain Valve	1	42.011.002

# **BE**

**POWER EQUIPMENT**

---

**If you need technical assistance call:**

**1-866-850-6662**

**(8:00am - 4:30pm PST, Mon - Fri)**